

# Use of Localized HEPA Filtered Ventilation for Radiological Work



---

Jerry Eby  
Fluor Hanford, Inc  
ALARA Center of Technology



# ALARA Goals

---

- Workers need to practice:
  - Reducing radiation exposure to workers
  - Limit the spread of radioactive contamination
  - Minimize the production of radioactive waste



# Localized HEPA Filtered Vent

---

- A good engineered control method
  - Used to capture radioactive particles produced during work
  - Used to control existing loose surface contamination in a work zone



# HEPA filtered Vent Systems

---

- Portable unit:
  - Small, compact
  - HEPA filtered and pre-filters
  - Can be cleaned without damaging the aerosol leak test certification
  - Used primarily with glovebags





# Systems (Continued)

---

- Exhausters
  - Larger units, higher flow. At Hanford to 2000 CFM based on an Notice Of Construction.
  - HEPA and pre-filtered
  - Can be dampened to regulate flow
  - Hoses can be branched to better control the air flow

# Typical Portable Unit

- GM-80 unit
- Has speed controller
- Four stages of Filtration
- Bag can be emptied w/o breaking the aerosol leak testing Seal
- Has a speed controller, to control volume of air



# Break Down of a GM-80 Vac



# HEPA Filtered Vacuum Cleaner

## Wet and Dry Vacuum Cleaner



# In-Line Chip Collectors and Filters


- In-Line chip collector (rock stoppers) can be as simple as a can with a lid with two ports.
- In-Line filters can be HEPA, pre-filter material, scotch foam or other material






# In-Line HEPA Pre-Filter

Used between the Source and vacuum



# Vent Snorkel in a Hot Cell

- Allows concentration or different geometry of air flow depending on the tip used.
- Flexible, easily adjustable to the work. Length easily modified.



# Shrouded Tools w/ Vacuums

- Shrouded tools used with HEPA vacuums give additional protection to the worker.
- Collects a high percentage of debris created during work.





# Shrouded Tool in Use

- A shrouded tool attached to a HEPA Filtered vacuum cleaner is used, remove radioactively contaminated paint from a floor surface.




# HEPA Filtered Vacuum

- A HEPA Filtered vacuum cleaner supporting the shrouded tool, used to remove contaminated paint.




# MAC-21 Drum Hood

- HEPA Filtered exhauster
- Mounted hood for drums
- Gives up to 350 FPM flow over the drum lid
- 55 and 85 Gal. Drums



# Drum Scoop

- Drum hood with an upper shield developed for 55 gallon drums
- Localized ventilation scoop in the left front.



# HEPA Filtered Vent Exhauster

- 750 CFM Unit
- Pre-filtered
- HEPA filtered
- Dampened at the exhaust
- Some units are dust and weather proof
- 110 Volt AC





# Erecting Tent with Positive Air

- Using a HEPA filtered exhauster to inflate a tent in a contaminated canyon. Keeps the inside (work area) clean for future work.




# Erected tent with Positive Air

- Once erected, scaffolding is added inside to support the tent. Work may commence without Personal Protective Equipment for the worker.



# Ventilation Intake Scoop


- A Vent scoop built into the drying assembly also removes any radioactive contaminates.






# Vent Scoop for Sampling

- A Negative Vent Scoop is placed adjacent to the sample location and was able to allow work without a glovebag.




# Filter Change out Tent Vent

- An exhauster is used for tent vent and branched for localized ventilation for a filter replacement.



# Tent Exhauster for Pit Work

- Exhauster, HEPA Filter unit and ducting supporting pit work inside a tent (greenhouse).



# Pit HEPA Filtered Exhaust Trunk


- The suction ducting inside the transfer pit. Ducting is placed within two feet of the floor to better capture contaminants.






# Field HEPA Filtered System

- A copus blower with an in-line HEPA filter with and octopus trunk.




# Field System In Use

- Multiple legs of the HEPA Filtered system, servicing multiple jobs




# Vent for Tank Sample Truck

- Three exhausters used for negative HEPA filter vent during sampling. Items are in standby storage.
- Front unit is 1000 CFM unit.



# Tank Sampling Truck

- Tank sampling truck in standby storage. Ventilation connections are bagged in yellow.





# Smoke Test of Air Flow

- Using baby powder, the worker can determine effectiveness of the installed negative HEPA filtered ventilation.



# Vent Trunk to Rad Work Area

- A HEPA filtered ventilation trunk has been run into the back of the work area for airborne radioactive contamination control.






# Training Workers on Vent Use

---

- Use mockup system to demonstrate air flow based on duct size
  - Use smoke/powder for visual effects
  - Use shields to demonstrate methods of increasing capture
  - Discuss workers' body position in relationship with the source and the vent
  - Use the standard flow chart
  - Teach to get within one duct diameter of the source


# Training RCTs in Use of Vent

- The ALARA Center trains RCTs, Operations and Maintenance personnel in the proper use of HEPA filter vacuum cleaners and exhausters




# Negative Vent Capture

- Effective capture is based on one duct diameter of the vent hose or less from the source. At one duct diameter, ~7.5% of the flow rate is present.



# With a Collar, Flow Increases


- Blocking the flow from the side of the hose increases the flow and capture of contaminants from the front of the hose. At one duct diameter ~10% of the flow rate is present





# Vent Training Area

- At the ALARA Center, a ventilation mockup is present to demonstrate air flow and capture of contaminants.





# Points of Contact at the Center

---

- Jerry Eby
- Ph.# 509-372-8961
- Fax# 509-376-7717
- E-mail: [jerald\\_l\\_eby@rl.gov](mailto:jerald_l_eby@rl.gov)
- Larry Waggoner
- Ph.# 509-376-0818
- E-mail: [larry\\_0\\_waggoner@rl.gov](mailto:larry_0_waggoner@rl.gov)